


Operating Manual Controller Single Split Air Conditioner

ceiling cassette, 5.0-230FJ

1. Remote Controller:



Button START/STOP (ON/OFF)

The air conditioner will start or stop operating. The receiver unit control panel's OPERATION Indicator Lamp (green) will light or go out.

To Set the Room temperature:

- **SET TEMP. ↓ (colder)**
Button to lower the temperature setting.
- **SET TEMP. ↑ (warmer)**
Button to raise the temperature setting.

Button „Mode“:

- COOL
Symbol must always be displayed!


Without function:

- AUTO
- HEAT
- DRY
- FAN

Button „FAN“:

- AUTO As the room temperature approaches that of the temperature setting, the fan speed becomes slower.
- HIGH High fan speed
- MED Medium fan speed
- LOW Low fan speed

2. Display Panel:



1) Temperature SET Indicator

*2) ECONOMY – Indicator

3) Operating Mode Indicator: Cooling

*4) SLEEP – Indicator

5) Transmit Indicator

6) Fan Speed Indicator

7) SWING – Indicator

*8) Timer Mode Indicator

9) Clock Indicator

*

The following keys **must not** be activated:*

- „ECONOMY (ECO)“
- „SLEEP“
- „Timer“

3. Important Information:

1) **Setting the fan speed:**

Each time the button „Fan“ is pressed, the fan speed changes in the following order:



About 3 seconds later, the entire display will reappear.

2) **Cooling Operation:**

- The Cooling mode will not operate if the preset temperature is set higher than the actual room temperature.
- **Temperature setting range:**
 - Min: 18 Grad
 - Max: 30 Grad

3) **Cancel TIMER – Operation:**

Use the “TIMER MODE” button to select “CANCEL”. The receiver unit control panel’s TIMER Indicator Lamp (orange) will light. The air conditioner will return to normal operation.

4) **Cancel SLEEP TIMER:**

Use the “TIMER MODE” button to select “CANCEL”. The receiver unit control panel’s TIMER Indicator Lamp (orange) will light. The air conditioner will return to normal operation.

5) **Cancel ECONOMY – Mode:**

Press the “ECONOMY” button again. “ECO” disappears from the Remote Control Unit display. Normal operation begins.

NOTE:

- ➔ **The air conditioners are in like-new condition. There are no scratches, dents, or other damage.**

Damage of any kind will be charged in full. This usually means at least a repainting of the housing.

The air conditioners should be treated with care!